

On-Hold Plus[™] 5000 Series

Connecting to Ordinary Phones via On-Hold Adapter Module:

Follow these 6 simple installation steps, and you'll have your OHP 5000 series connected to an analog phone system in no time.



Step 1:
Plug the AC adapter into a 110V power outlet.




Step 2:
Plug the other end of the power cord into the 9V DC jack on the back.



Step 3:
Plug one end of the supplied 6' phone cord into the jack labeled "1/2/3" on the back of the unit.



Step 4:
Plug RJ11 duplex jack into the phone plug socket coming out of the wall, and connect the other end of the 6' phone cord coming from the unit.



Step 5:
Plug the other supplied 6' phone cord into the other side of the RJ11 duplex jack.



Step 6:
Plug the other end of the 6' phone cord into your phone. That's all there is to it!

